

# RoboDk-Fanuc Connection Setup


by Shanlong Yu

With successful RoboDk driver installation on the Fanuc robot, project simulation in RoboDk can both ran in user interface and on robot simultaneously.

## Installation Steps:

### Step 1:


Install RoboDk with latest version and create a new station with the corresponding robot model from RoboDk's online library (Fanuc LR Mate 200iD/7L).



Installation Step 1

### Step 2:

Connect computer and Fanuc robot with ethernet, and change the computer IP address (TCP/IPv4) to 169.254.16.2 with subnet mask 255.255.0.0



Installation Step 2

### Step 3:

On the teach pendant (TP) of the Fanuc robot, setup robot IP address.

{Menu — Setup — Host Comm — TCP/IP — (ENTER)}

Enter the robot IP 169.254.16.144 and computer IP 169.254.16.2 as shown.



### Installation Step 3

### Step 4:

On TP, setup on Ethernet/IP

{Menu — I/O — Ethernet/IP}

Enter Connection1 configuration as shown (4 words) and set Enable to True.

After restarting the robot, Status should go from Pending to Online as shown.



### Installation Step 4

### Step 5:

Follow RoboDk Instructions on how to setup Fanuc robot drivers.

<https://robodk.com/doc/en/Robots-Fanuc.html#Fanuc>

Processes include: Driver files download and transfer the files to robot TP with a USB.

Please make sure that the driver file is up to date and corresponds to the latest RoboDk version.

Make sure the robot IP used in setup is 169.254.16.144

### Trouble Shooting:


With the ethernet addresses and connection setup correctly, you should be able to both ping the robot IP address from the computer using either terminal or RobotDk (connect to robot – ping) and ping the computer IP address from the robot TP from {Menu-Setup-Host Comm-TCP/IP-(ENTER)-PING}.

Ethernet hardware connection problem may be solved by switching ethernet cable to a different ethernet portal inside the Fanuc PC case.

## Connection Steps:

### Step 1 (Computer):

Open RoboDk software with the corresponding workstation, and right click the robot and click connect to robot in the drop-down list. Input the robot IP address (169.254.16.144)



Connection Step 1

### Step 2 (Robot TP):

Initialize the robot, then press FCTN9 (button on TP) and click Abort All.

Then, press Select—73 RDK\_S3 (Fanuc driver file that you transferred to the TP with USB) — Enter — (Shift+Reset) — (Shift+FWD).

If run successfully, we should see RDK\_S3 LINE 516/8 T1 Running Joint on the top of TP screen with Busy and Run status.




Connection Step 2

### Step 3 (Computer):

Should say Ready and then click connect. Hold the Deadman switch.

Running a simple joint movement program and right click select run on robot.

Finally, we should see you the robot's movement synchronizes with RoboDk' simulation.



Connection Step 3